



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI 51F710A. You'll find the answers to all your questions on the HITACHI 51F710A in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI 51F710A
User guide HITACHI 51F710A
Operating instructions HITACHI 51F710A
Instructions for use HITACHI 51F710A
Instruction manual HITACHI 51F710A

HITACHI
Inspire the Next

PROJECTION COLOR TELEVISION

Operating Guide for 51F710E, 57F710E, 51F710A, 57F710A and 65F710A

IMPORTANT SAFETY INSTRUCTIONS	2-3
FIRST TIME USE	4-17
THE REMOTE CONTROL	18-29
ON-SCREEN DISPLAY	30-55
USEFUL INFORMATION	56-67
END USER LICENSE AGREEMENT FOR HITACHI DTV SOFTWARE	68
APPENDIX	67
INDEX	67



As an Energy Star® Partner,
Hitachi, Ltd. has determined
that this product meets the
Energy Star® guidelines for
energy efficiency.



[Your user manual](#)
[HITACHI 51F710A](#)

Manual abstract:

Read these instructions. 2. Keep these instructions. 3. Heed all warnings. 4. Follow all instructions. 5. Do not use this apparatus near water. 6.

Clean only with a dry cloth. 7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. 8.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding 16.

17. 18. 2 Note to the CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-44 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical. Important Safety Instructions Power source This television is designed to operate on 120 volts 60 Hz, ac current. Insert the power cord into a 120 volt 60 Hz outlet. To prevent electric shock, do not use the television's (polarized) plug with an extension cord, receptacle, or other outlet unless the blades and ground terminal can be fully inserted to prevent blade exposure. Never connect the television to 50 Hz, direct current, or anything other than the specified voltage. Caution Never remove the back cover of the television as this can expose you to very high voltages and other hazards. If the television does not operate properly, unplug the television and call your authorized dealer or service center. Caution Adjust only those controls that are covered in the instructions, as improper changes or modifications not expressly approved by HITACHI could void the user's warranty.

Warning · To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. · The television should not be exposed to dripping or splashing and objects filled with liquids, such as vases, should not be placed on the television. Warning · Do not place any objects on the top of the television which may fall or cause a child to climb to retrieve the objects. · Projection TV's are heavy and can mark or damage floor surfaces (especially wood flooring) if moved improperly. Do not slide or force TV into position. Always roll TV allowing casters at bottom of unit to help steer and position the TV. Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hitachi America, Ltd. Home Electronics Division may void the user's authority to operate the equipment. Note This television receiver will display television closed captioning, (or), in accordance with paragraph 15.119 and 15.

122 of the FCC rules. Public viewing of copyrighted material Public viewing of programs broadcast by TV stations and cable companies, as well as programs from other sources, may require prior authorization from the broadcaster or owner of the video program material. This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights.

Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited consumer uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited. Note This digital television is capable of receiving analog basic, digital basic and digital premium cable television programming by direct connection to a cable system providing such programming. A CableCARD provided by your cable operator is required to view encrypted digital programming. Certain advanced and interactive digital cable services such as video-on-demand, a cable operator's enhanced program guide and data-enhanced television services may require the use of a set-top box.

For more information call your local cable company. Note · There are no user serviceable parts inside the television. · Model and serial numbers are indicated on back side of the television. Prevention of screen burn This Wide Screen TV is designed to display wide screen pictures..



[Your user manual](#)
[HITACHI 51F710A](#)